

INSTALLATION GUIDE





Shell

Reusable with the refill pods that are included in your pack.



Refill Pod



InkPod Cartridge Shell + Refill Pod

How to Install Your First InkPod Cartridge



1. Remove the clear plastic clip that protects the cartridge. Hold the cartridge in one hand and pull up on the plastic tab with your other hand to separate the clip from the cartridge.



2. Remove protective yellow sealing tape that covers the printhead. We recommend doing this over a trash can as some ink might escape when removing the tape.



3. Install the cartridge into your printer and start printing!



When your InkPod cartridge is installed, a "Used Cartridges" alert message may appear on your printer's display. Select "OK" to bypass this message and continue printing.



Easily keep an eye on ink levels. InkPods track real-time ink levels on your printer's display so you know exactly when to replace your ink.

How to Replace a Refill Pod

When the first refill pod runs out of ink, follow the replacement instructions below to install a new refill pod.



1. Remove the empty InkPod cartridge from the printer.



2. Press the gray "push" tab to release the empty refill pod from the reusable shell.



3. Unwrap a new refill pod and remove the black cap on the bottom of the pod.



4. Insert the new refill pod into the reusable shell and press down to secure.



5. Install the InkPod cartridge into your printer and start printing!

The shell should only be used with the refill pods that are included in your pack. If the shell is overused, the print quality will deteriorate and may cause damage to your printer. After using your last refill pod, please recycle the entire InkPod cartridge pack (shell and refill pods).

If you purchased both a black and a color InkPod cartridge pack, please note that the black and color shells are not interchangeable. Mixing shells and refill pods may damage your printer.

For product help and instructions visit LDProducts.com/InkPods.